CABINET PARTS

REFRIGERATOR

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00

KitchenAid® **(White) (Biscuit) (Black)**



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	2315123	Energy Guide
	2308392	Owner's Manual
	2303925	Service Sheet
	2303929	Wiring Sheet
	2220407	Modular Icemaker Service Sheet
	2308395	Instruction Sheet, Door Removal
2	2174748	Front Roller (2)
3	3400517	Screw
4	2196236	Roller (Rear) (2)
5	489427	Screw
6	2155013	Clip, Grille
7	489478	Screw
8	2156056	Shim
9	2203771	Hinge Top (RC)
11	8281227	Screw
12		Hinge Cover
	2203407W	White
	2203407T	Biscuit
	2203407B	Black
13	2304322	Bottom Hinge (RC)
14		Filler, Wrapper
	2196094	White
	2196150	Biscuit
	2196097	Black
15		Grille
	2303292W	White
	2303292T	Biscuit
	2303292B	Black
16	489497	Screw
17	489464	Screw
18	940139	Drain Fitting
19	1108438	Extension Tube
20	1108439	Clip, Drain Tube
21	2188739	Cover, Unit
22		Cabinet (Not A Serviceable Part)
23		Hinge Cover
	2203408W	White
	2203408T	Biscuit
	2203408B	Black
24	549193	Clamp, Service Cord
25	489084	Screw
26	2155311	Door Closer, RC
27	489483	Screw
28	2260507	Housing, Water Filter
29	4396841	Water Filter
30		Cap, Water Filter
	2260502W	White
	2260502T	Biscuit
	2260502B	Black
31	489500	Screw
32	3400113	Screw
33	2303141	Bottom Hinge (FC)
34	2260519	Block, Housing Support
35	2255012	Tube, Filter Outlet
36	2203770	Hinge Top (FC)
37	2305220	Tube, Filter Inlet
38		Button, Water Filter
	2260503W	White
	2260503T	Biscuit
	2260503B	Black
39	2223751	Door Closer, FC
40	2305373	Clamp, Cord

REFRIGERATOR LINER PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2255612	Escutcheon, Meat Pan Control
3	2301339	Slide Meat Pan Control
4	2257741	Louver
5	2301235	Slide, Door Control
6	2179404	Wine Rack
9	2206273	Shelf Ladder
10	489478	Screw
11	486298	Screw (2)
12	2301234	Housing, Door Control
13	2150331	Cover, Conduit
15	2216112	Air Diffuser Assembly
16	2212240	Cover, Air Diffuser
18	2162085	Socket
19	2305226	Reservoir
20	2255743	Light Bulb
21	2209769	Light Lens
22	488280	Screw
23	2256035	Bracket, Dual Crisper
24	2256037	Wire Harness, Dual Crisper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2301072	Frame Assembly (2)
2	2301023	Snack Bin Asm (Includes 24 & 25)
3	2301567	Cover, Crisper (Includes 11, 12, 16, 17, 19 & 20)
4	2196485	Stud Assembly
5	3400894	Screw
6	2301028	Glass, Meat Cover
7	2301027	Glass, Cover
8	2301568	Cover, Meat Pan (Includes 16 & 18)
9	2196483	Stud Assembly
10	2301031	Crisper Pan Asm (Includes 21 & 24)
11	2301026	Slide, Humidity Control
12	2301025	Knob, Humidity Control
13	2301084	Shelf & Roller Assembly (2)
14	2301022	Meat Pan Asm (Includes 24 & 27)
15	8281158	Screw
16		Glide Assembly
	2301548	Right Side
	2301549	Left Side
17	2301115	Gasket, Rear
18	2301126	Deflector
19	2301116	Gasket, Front
20	2301117	Gasket, Side (2)
21	2301001	Window, Crisper Pan
22	2301566	Shelf, Snack Pan
23		Support Assembly
	2301569	Right Side
	2301570	Left Side
24		Cap, Corner
	2301016	Right Side
	2301017	Left Side
25	2301006	Window, Snack Pan
26	2188212	Roller (2)
27	2301227	Window, Meat Pan
28	489439	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
5	2196483	Stud Assembly
6	2301139	Basket, Tall
7	8281158	Screw
11	3400893	Screw
12	2301134	Front, Basket
14	2205837	Shelf (2)
15	2301140	Basket, Sloped
16	8534064	Screw (12)
17	842534	Clip, Air Duct
18	2301138	Basket, Top
19	2198587	Cover, Emitter
21	2198697	Gasket, Ladder
22	2198635	Spring
23	2198634	Pin
24		Glide Assembly, Top Basket
	2301540	Right Side
	2301541	Left Side
25	1115373	Switch, Rocker Arm
26	2220398	P.C. Board Emitter
27	2255590	Cover, Ice Maker
28	2212321	Slide, Ice Maker Mounting
29	489478	Screw
30	489214	Screw
31		Glide Assembly, Middle/Bottom Basket
	2301542	Right Side
	2301543	Left Side
32	2162085	Light Socket
33	2255743	Light Bulb
34	8281185	Screw
35	2198633	Flipper
36	2255561	Cover, Receiver
37	2301340	Slide, Ice Maker Shut Off
38	2255114	P.C. Board, Receiver
39	2198643	Lens
40	2198589	Light Shield
41	2212340	Light Lens
42	2198641	Bracket, Ice Maker Cover
43	2155597	Socket, Light
45		Ladder
	2198609	Left Side
	2198610	Right Side
46	2303234	Shield, Wiring

MOTOR AND ICE CONTAINER PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00

(White) (Biscuit) (Black)



MOTOR AND ICE CONTAINER PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	2305336	Ice Bin
2	2305294	Crusher Bin
3	2211590	Auger
4	2257021	Blade, Stirring
5	1119007	Spacer, Flat (6)
6	2305244	Cover, Crusher
7	2257024	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2198602	Block, Blade
12	489229	Roll Pin
13	2257022	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2220457	Coupling
17	8281164	Screw
18	3400065	Screw
19	2305382	Rubber Boot
20	2305214	Latch, Bin
21	2198608	Spring, Latch
24	2212369	Holder
25	2220458	Coupling, Bottom
26	2198628	Seal
27	2212370	Washer
29	2198607	Spring
30	2305243	Drive Shaft
32	2252130	Dispenser, Motor
33	2305208	Bracket, Motor
35	8281163	Screw
36	2212365	Sleeve, Coupling

REFRIGERATOR DOOR PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item #6)
	2303139W	White
	2303139T	Biscuit
	2303139B	Black
2	2301486	Door Compartment (Includes 7)
3	2223434	Door Bin (4)
4	3400012	Screw
5	2219698	Stud, Handle
6		Door Gasket, Magnetic
	2221302	Mist Beige
	2221313	Black
7	2159124	Gasket
8		Handle
	2255516W	White
	2255516T	Biscuit
	2255516B	Black
9	488208	Screw
10	2182178	Door Closer, Upper Cam
11	489420	Screw
12		Bracket, Door Stop
	2303113	Chrome
	2303113B	Black
13		Screw
	8533976	Chrome
	8533975	Black
14	2165792	Butter Dish
15	2193409	Holder, Beverage
16	8531691	Nameplate

FREEZER DOOR PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes #8 And Dispenser Front Parts)
	2303138W	White
	2303138T	Biscuit
	2303138B	Black
2		Handle
	2255516W	White
	2255516T	Biscuit
	2255516B	Black
3	2223559	Trivet (3)
4	2219698	Stud, Handle
7	488208	Screw
8		Door Gasket, Magnetic
	2221303	Mist Beige
	2221314	Black
12	2223752	Door Closer, Upper Cam
13	489420	Screw
14		Bracket, Door Stop
	2303113	Chrome
	2303113B	Black
15		Screw
	8533976	Chrome
	8533975	Black
17	3400012	Screw

DISPENSER FRONT PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
3	2305202	Bracket, Motor
4	2305242	Connector, Door Bracket
5	2305262	Motor, Ice Door
6	2305258	Door, Ice
7	2305204	Support, Ice Door
8	4449745	Screw (4)
10	2305236	Spigot
11	2305366	Separator Assembly
12	2303946	Electronic Control (Core)
13		Pad, Water
	2305307CE	For White Model
	2305307MN	For Biscuit Model
	2305307GE	For Black Model
14	2305287	Lens, Front Cover
16	2304140	Cover, Electronic Control (User Interface)
17		Pad, Ice
	2305306CE	For White Model
	2305306MN	For Biscuit Model
	2305306GE	For Black Model
20	2305342	LED Assembly
21		Front Cover, Housing (Not Available, Order #23)
22		Tray, Housing
	2315111W	White
	2315111T	Biscuit
	2315111B	Black
23		Front Cover Assembly (Includes Items 13, 14, 16, 17, 20 & 21)
	2305312W	White
	2305312T	Biscuit
	2305312B	Black

AIR FLOW PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2182120	Fan Scroll
2	2155590	Retainer Fan Motor
3	2198595	Air Scoop
4	2212377	Air Duct, Upper
5	2198580	Air Duct Freezer
6	2188824	Bi−metal, Defrost
7	2220569	Fan Motor
8	2169142	Fan Blade
9	2188819	Thermister
10	2176759	Fan Grommet (2)
12	2187824	Harness, Fan Evaporator (Includes #6)
13	2155789	Gasket, Evaporator Cover
14	2172840	Strap
16	2203876	Gasket
17	2206314	Cover, Evaporator
18	8281159	Screw (6)
21	489478	Screw
22	2203595	Support, R.S.
23	2203596	Support, L.S.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2212005	Control Box
2	2219875	Switch
3	3196537	Screw (4)
4	2216879	Cover, Control Box
6	2304006	Electronic Control
7	8281244	Screw (4)
8	940014	Hole Plug
9	1115374	Clip, Wiring
10		Insert, Control Board (Not Available, Order #6)
17	2162085	Light Socket
19	2255743	Light Bulb
20	2216115	Control Box Harness
25	2255619	Overlay, Control Box

UNIT PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
2	2225834	Fan, Blade
3	2223953	Condenser Assembly
4	489464	Screw
5	2216914	Clip, Condenser
6	2261599	Tube, Condenser to Heat Loop
7	2304289	Heat Shield And Drain Pan
8	2205765	Tube Suction
10	8533993	Screw
12	4387731	Cover (Service Only)
13	2154697	Overload (Service Only)
15	2255199	Clip, Retaining
16	2255198	Start−Device, Combination (Start Relay and Overload) for Production Compressor Only
17		Capacitor
	999532	Production
	1118576	Service
20	2206281	Unit Cover, Bottom
21	489396	Clip
22	2188823	Evaporator
23	2161324	Clip
24	2188727	Motor, Fan
25	1105523	Tray, Evaporator
26	2187969	Harness, Unit
27		Drier
	2199167	Production
	4387019	Service
28	2255197	Compressor (Includes Items 12, 13, 17, 27, 29, 31 & 39) (Also Order 876765 Tube Kit)
29	2183454	Relay (Service Only)
30	2157397	Unit Mounting Frame
31	4387765	Wire, Capacitor (Service Only)
32	2181929	Bracket, Fan Motor
33	2188175	Heater, Defrost
34	2304287	Clip, Heater
37	489373	Screw
39		Grommet (4)
	1100826	Production
	4387558	Service
40	489340	Screw
41	2196202	Air Baffle
42	2155547	Clip, Heat
48	2305374	Unit Mounting Rail
49	8281232	Screw
50	2260517	Guard, Fan
51	2161302	Sleeve
52	2172840	Wire Tie
53	489427	Screw
55	489478	Screw
59	2208280	Clip, Wire & Tube
63	2305227	Union

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

5.0 oz.
(R−134A)

ICEMAKER PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2256096	Fitting and Water Tube
5	628379	Clip, Fuse
10	2305225	Smart Valve
16	2305274	Clip, Tube
18	2174358	Cover
19	488649	Screw
20	2255835	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
22	628356	Bearing & Inlet
23	627843	Ejector
24	2198598	Ice Stripper
25	2194712	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
29	2303583	Bracket, Ice Maker Mounting
30	489276	Screw
32	2187467	Harness, Wiring
35	626678	Module Assembly (Includes Items 37 & 38)
37	626676	Motor
38	489136	Screw
100	2198597	Icemaker Assembly

OPTIONAL PARTS

For Models: KSRF25FRWH00, KSRF25FRBT00, KSRF25FRBL00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch−Up Material

	*350942	Primer, White (12 Oz. Spray Can)
	*350939	Enamel, Black (12 Oz. Spray Can)
	*350930	Enamel, White (12 Oz. Spray Can)
	*4392901	Enamel, Biscuit (12 Oz. Spray Can)
	*8171357	Enamel, Graphite (12 oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	4392899	Brush Touch−Up Kit (Biscuit)
	72032	Brush Touch−up Kit (Black)
	80051	Brush Touch−up Kit (Graphite)

*__Important:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

Miscellaneous

	8129	Coil Brush
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
	876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" X 2−5/8)
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	503695	Cork, Sealer (1/4 Pound)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector
	2217192	Cleaner, Stainless Steel
	2305360	Ice Container−Crusher Assembly

Refinishing Material

	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)
	4392900	Enamel, Biscuit (1 Qt. Uncut)
	8171358	Enamel, Graphite

TORX SCREW WRENCH

	1117510	Torx Key

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST